

DOOR CROWN MOULDING**803-00**

Chamber door crown

Pine, white

Door module 8

1 pc./package

EAN 6418172028038

**APPLICATION**

For door top edge decoration in place of cover strip.

BEFORE INSTALLATION

Always allow the product temperature and humidity to stabilise prior to installation.

Keep the products at the intended installation premises for 2-3 days. The room temperature must be around 20°C and relative air humidity less than 50%.

INSTALLATION

1. Measure the distance between the farthest point of the groove behind door crown and the crown bottom edge. In general, this distance is approx. 136 mm. Mark the height on the wall as measured from the cover strip bordering the door. Measure and mark the same distance on the other side of the door.
2. Place the attachment strip that came with the crown over the middle of the door, with the strip upper edge at the marked location, and screw the strip to the wall.
3. Place the crown on the wall so that the strip now attached to the wall is inserted in the crown groove. Check that there is no gap under the crown, between the strip and the crown.
4. Attach the crown by screws to the attachment strip on the wall, from above the crown.

INSTALLED PRODUCT = APPROVED PRODUCT

Any manufacturing faults discovered in the panels must be notified before their installation.

ATTENTION!